


ASSEMBLY INSTRUCTIONS

Schaffenburg

— OFFICE FURNITURE —

DEXTRO HVS DUO

Manual height adjustable desk frame



70kgx2
(154lbsx2)
RATED



WARNING: FAILURE TO COMPLY WITH OR OBSERVE ALL ASSEMBLY, SAFETY AND OPERATION INSTRUCTIONS AND WARNINGS REGARDING THE USE OF THIS PRODUCT MAY RESULT IN SERIOUS BODILY INJURY.

Important information

Read the entire instruction manual before you start installation and assembly.

This product is not intended for use by young children without supervision.

This product contains small items that could be a choking hazard if swallowed. Keep these items away from children.

This product is intended for indoor use only. Using this product outdoors could lead to product failure and personal injury.

This product can be used by children from 8 years old (supervised) to Adult. Users with disabilities or lack of experience and operating knowledge should be supervised and given careful instruction prior to using this product. The desktop should never be sat on and children should be prohibited from having unsupervised contact with the product.

Cleaning and user maintenance shall not be made by children without supervision.

If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or a similarly qualified person in order to avoid a hazard.

IMPORTANT: Ensure that you have received all parts according to the component checklist prior to installation. If any parts are missing or faulty, telephone your local distributor for a replacement.

QUICK TIP: DO NOT overtighten screws during installation.

CAUTION:

- Please place the product away from corrosive gas, water and dusty environment.
- Please do not disassemble all the components, otherwise, it will be seen as the withdrawn of the warranty service.



Disposal:

This marking indicates that this product should not be disposed with other household wastes throughout the EU. To prevent possible harm to the environment or human health from uncontrolled waste disposal, recycle it responsibly to promote the sustainable reuse of material resources. To return your used device, please use the return and collection systems or contact the retailer where the product was purchased. They can take this product for environmental safe recycling.

Tools
Needed




Component Checklist




x2

1 Assembling the Frame


- Loosen the two screws by using the Allen key.
- Adjust the frame length to suit the desktop.
- Retighten all screws.



- Attach the telescopic crossbar to the lifting columns as shown by using the screws identified in the illustration.




- Tighten all screws with a proper screwdriver.




2 Installing the Side Brackets

- Attach the two side brackets to both ends of the frame by using the four screws and tighten all screws with an Allen key.




- Drill mounting holes under the desktop, then remove the desktop.



Attention: the maximum depth of holes is 3mm.


3 Assembling the Frames

- Connecting the two frames using the connecting bar and screws.
- Tighten all screws.




4 Installing the Feet

- Place the feet on the lifting columns as shown.
- Insert the screws as shown and fix them under the lifting columns.




5 Installing the Sync Rod

- With the frame positioned upright, turn the knob as shown counterclockwise to loosen the sync rod.
- Adjust the sync rod to match the frame's width then.




- Notice: Match the red line on the sync rod with the right side of left leg. Match the right side of the right knob of the sync rod with the red line on the rod of the gearbox.
- Retighten the sync rod by using the knob.




6 Installing the Desktop

- Place the desktop on the frame and insert the desktop mounting screws.
- Tighten all screws.



- Insert the drive rod module into the upper part of the lifting column as shown.
- Fix the fixing plate onto the back of the desk by using the screws identified in the illustration.



- Each foot pad can be adjusted independently for fine tuning.
- Slightly turn the foot pad to lower or raise the base.
- Use a level to make sure the desktop is even.

